## EX 8B PROCEDURE:

- 1. **Open Cisco Packet Tracer** and create a new project workspace.
- 2. Add devices: Drag a wireless router and three PCs (or laptops) onto the workspace.
- 3. **Connect the PC to the router**: Use a copper straight-through cable to connect the PC to the Ethernet port of the wireless router (e.g., FastEthernet0).
- 4. **Configure the wireless router**: Click on the wireless router icon, go to the GUI tab, and set the **SSID** under the Wireless settings.
- 5. **Enable DHCP**: In the router's setup tab, ensure DHCP is enabled to automatically assign IP addresses to connected devices. Set the DHCP range.
- 6. **Set up security**: Under the Wireless Security settings, choose a security mode (e.g., WPA or WEP) and set a passphrase or key.
- 7. **Configure each PC for wireless access**: For each PC, click on it, go to the Physical tab, remove any wired Ethernet module, and install a wireless adapter (e.g., WPC300N).
- 8. **Power on each PC**: After installing the wireless module, power on each PC.
- 9. **Connect PCs to the wireless network**: On each PC, go to the Desktop tab, select PC Wireless, find Network and enter the security key to connect.
- 10. **Verify connectivity**: Use the command prompt on each PC to ping the router's IP address (e.g., 192.168.0.1) and ensure successful communication.