EX 10B PROCEDURE:

- 1. **Open Cisco Packet Tracer** and create a new project workspace.
- 2. **Add devices**: Drag a wireless router, a DHCP server (simulated with a PC), and an Internet cloud icon into the workspace.

3. Connect devices:

- Connect the wireless router to the Internet cloud using a copper straight-through cable.
- Connect the DHCP server to the wireless router's LAN port (e.g., FastEthernet0).

4. Configure the wireless router:

- Click on the wireless router and go to the GUI tab.
- Under the Wireless settings, set the SSID (e.g., "HomeNetwork").
- In the **Setup** tab, ensure DHCP is enabled and configure DNS settings (e.g., DNS Server: 208.67.220.220).

5. Set up DHCP on the DHCP server:

- Click on the DHCP server (PC), go to the Desktop tab, and open the command prompt.
- Configure a DHCP scope
- This will allow devices to receive IP addresses in the range of 192.168.0.1 to 192.168.0.254.

6. Configure IP address for the wireless router:

- Access the CLI of the wireless router and assign an IP address
- 7. **Add clients**: Drag several PCs or laptops into the workspace and connect them wirelessly to the router.
- 8. **Configure clients for wireless access**: On each PC, go to the Desktop tab, select Wireless, find "HomeNetwork," and connect using any security key if prompted.
- 9. **Verify DHCP functionality**: On each PC, open Command Prompt and run ipconfig /all to confirm they receive IP addresses from the DHCP server.
- 10. **Test Internet connectivity**: From any connected PC, use Command Prompt to ping an external site to verify that internet access is functioning through the cloud.